



nedis

TVWM5530BK INSTALLATION MANUAL



	B (x2)	C (x2)	M5x14 (x4) M-A	M6x14 (x4) M-B	M8x20 (x4) M-C	M6x30 (x4) M-D				
	A (x1)	F (x1)	G (x8)	H (x1)	I (x1)	M8x30 (x4) M-E	D5 (x4) M-F	D8 (x4) M-G	(x8) M-H	(x4) M-I
	D (x2)	E (x1)	J (x1)	W-A (x4)	W-B (x4)	W-C (x4)				

